## WINTER- 18 EXAMINATION Model Answer Subject Code:

17658

1

#### Important Instructions to examiners:

- 1) The answers should be examined by key words and not as word-to-word as given in themodel answer scheme.
- 2) The model answer and the answer written by candidate may vary but the examiner may tryto assess the understanding level of the candidate.
- 3) The language errors such as grammatical, spelling errors should not be given moreImportance (Not applicable for subject English and Communication Skills.
- 4) While assessing figures, examiner may give credit for principal components indicated in the figure. The figures drawn by candidate and model answer may vary. The examiner may give credit for any equivalent figure drawn.
- 5) Credits may be given step wise for numerical problems. In some cases, the assumed constantvalues may vary and there may be some difference in the candidate's answers and model answer.
- 6) In case of some questions credit may be given by judgement on part of examiner of relevant answer based on candidate's understanding.
- 7) For programming language papers, credit may be given to any other program based on equivalent concept.

Q. No.	Sub Q. N.	Answers	Marking Scheme
1	a)	Attempt any THREE of the following:	12- Total Marks
	(i)	What is multicore processor? Describe in brief.	4M
	Ans:	<ul> <li>Multicore Processor:         <ul> <li>It is an integrated circuit in which two or more processors core have been packaged for enhanced performance, reduced power consumption and more efficient simultaneous multitasking.</li> <li>In multi core technology architecture, a single physical processor contains the core logic of two or more processors and these processors are packaged into a single integrated circuit.</li> </ul> </li> <li>The multicore technology is mainly used for parallel computing which increases computer speed and efficiency.</li> <li>Multiple processes are used in mobile devices, desktops, workstations and servers.</li> <li>Multicore processors will give the benefits to all software especially for multithreaded program.</li> </ul>	Descript ion -4M

## WINTER- 18 EXAMINATION <u>Model Answer</u> Subject Code:


17658

(ii)	State any four features of IDE.	4M
Ans:	Features of IDE-	Any four
	1) IDE normally consists of source code editor, a compiler, build automation tools and	features -4M
	debugger.	
	2) It supports for defining a processor family and its version.	(1M each)
	3) Supports a user definable assembler to support a new version or type of processor.	
	4) Provides multiuser environment.	
	5) Supports conditional and unconditional break points.	
	6) Provides debugger.	
(iii)	State four features of Zigbee.	4M
Ans:	Zigbee features (any4):-	Any four
	• IEEE Standard 802.15.4	features
	• Frequency (GHz) 0.868, 0.915, 2.4	-4M,
	Maximum bit rate (Mbps) 0.250 or 250 Kbps, low bit rate	(Each
	• Typical data throughput (Mbps) 0.2	feature-
	Maximum (Outdoor) Range (Meters) 10-100	1M)
	Relative Power Consumption Very low	
	Battery Life Months to years	
	• Network Size 64,000+	
(iv)	Draw the labeled interfacing diagram to interface relay with 89C51 microcontroller.	4M
Ans:		Correct
A1131		labeled
		diagram

## WINTER- 18 EXAMINATION <u>Model Answer</u> Su

Subject Code:

17658



## WINTER- 18 EXAMINATION <u>Model Answer</u> Subject

Subject Code: 17658

**Block** Ans: Input devices/interfacing diagram devices drivers ckts -2M Timer/ Interrupt counter **Descript** controller ion of hardwar processor Data Program Application e units-Power memory memory ckts supply 4M Parallel Serial port ports O/P devices I/ P devices, driver ckts OR Input devices interfacing and driver circuits Program Power Processor memory and supply, Data memory System Reset Applicat and Oscilla specific tor circuit Serial circuit Timers ommunication Port Interrupt Parallel Controller Ports Output devices interfacing and driver circuits

#### WINTER-18 EXAMINATION

Model Answer Subject Code:

17658

.

### **Explanation:**

**Subject Name: Embedded Systems** 

The embedded system consist of different components embedded into it as follows:

- 1) Embedded Processor
- 2) Power supply, reset and Oscillator circuits
- 3) System timers
- 4) Serial communication port
- 5) Parallel ports
- 6) Interrupt controller
- 7) Output and Input Interfacing and driver circuits
- 8) System application specific circuits
- 9) Program and Data memory

#### **Processor:**

The processor is the heart of embedded system. The selection of processor is based on the following consideration

- 1. Instruction set
- 2. Maximum bits of operation on single arithmetic and logical operation
- 3. Speed
- 4. Algorithms processing and capability
- 5. Types of processor( microprocessor, microcontroller, digital signal processor, application specific processor, general purpose processor)

### Power supply, Reset, Oscillator circuit and system timers:

#### Power source:

Internal power supply is must. Es require from power up to power down to start time task. Also it can run continuously that is stay "On' system consumes total power hence efficient real time programming by using proper 'wait' and 'stop' instruction or disable some unit which are not in use can save or limit power consumption.

### **Clock / oscillator Circuits**

The clock ckt is used for CPU, system timers, and CPU machine cycles clock controls the time for executing an instruction. Clock oscillator may be internal or external .It should be highly stable

### Real time clock(RTC):

It require to maintain scheduling various tasks and for real time programming RTC also use for driving timers, counters needs in the system.

### Resets Ckts and power on reset:

Reset process starts executing various instruction from the starting address. The address is set by the processor in the program counter. The reset step reset and runs the program in the following way

- 1. System program that execute from beginning
- 2. System boot up program
- 3. System initialization program

## WINTER- 18 EXAMINATION Model Answer Subject Code:

17658

6

#### **Serial and Parallel communication ports:**

Serial communication port and parallel communication ports are used to interface serial and parallel devices with the system and communicate between processor and devices.

### Interrupt controller:


It is used to receive interrupt from various sources and resolve the priority and provides the service to that interrupts.

### Input and output interfacing and driver circuits:

Characteristics of input or output devices may be different from the processor like voltage and current requirement to drive that specific device, hence driver circuits are needed to drive input or output devices.

### **Program and Data memory:**

The most microcontroller have inbuilt separate memory to store data and program. Following are types of memories used in embedded system.



(ii)	State the methods of task synchronization. Describe semaphore with suitable example.	6M
Ans:	The methods of task synchronization are:  • Semaphore	State or List of
	Message queue.	methods
	Mutual exclusion.	-2M

## WINTER- 18 EXAMINATION

Model Answer Subject Code:

1	7	6	5	8
---	---	---	---	---

7

Dead lock.

**Subject Name: Embedded Systems** 

- Mailboxes.
- Message Queues.

Descript ion-3M

### **Semaphores:**

## Example -1M

- It is a system of sending message by using flags. Multiple concurrent threads of execution with an application must be able to synchronize their execution & co-ordinate mutually exclusive access to shared resources.
- To fulfill this requirement RTOS kernel provides a semaphore object that one or more threads of execution can acquire or release for the purpose of synchronization or mutual exclusion. Semaphore is like a key that allows a test to carry out some operation or to access a resource. When task acquires the semaphore, it receives an access to the resource.
- The number of times the semaphore can be acquired by the task is determined by the resource count of a semaphore.
- A resource count is decremented by one, when a task acquires the semaphore and its resource count is incremented by one when a task releases the semaphore.
- A kernel supports many different types of semaphores :

**Binary:** Binary semaphores are used for both mutual exclusion and synchronization purposes. A binary semaphore is used to control sharing a single resource between tasks..

**Counting:** it is a semaphore that increments when an IPC is given by a task. It decrements when a waiting task unblocks and starts running.

**Mutex or Mutually Exclusion semaphore**: In this a mutex key is used to lock the shared resource, if it is acquired by the task, so that any other task cannot acquire until it is released.

### **Example of using semaphores for Synchronization:**

Assume two concurrent process P1 and P2 having statements S1 and S2. We want in any case S1 should execute first. this can be achieved easily by initialize Sem=0;

```
In process P1
{
// Execute whatever you want to do
// before executing P2
S1;
signal(Sem);
}
in process P2
{
wait(Sem);
```

S2;

# WINTER- 18 EXAMINATION <u>Model Answer</u> Subject Code:

17658

.

). lo.	Sub Q. N.		Ansv	wers	Marking Scheme
		Attempt a	ny FOUR of the following:		16- Tota Marks
	a)	Compare I	Harvard and Von Neuman architectu	ure with a suitable diagram.	4M
	Ans:	Sr. No.	Harvard architecture	Von-Neumann architecture	Any fou
		1	Program memory Address CPU Address memory	Data Program and Data Data memory	4M which includes 1M for diagram
		2	Harvard architecture uses physically separate memories for their instructions and data.	Von –Neumann architecture uses single memory for their instructions and data.	
		3	Requires separate and dedicated buses for instructions and data.	It requires single bus for instruction and data	
		4	Design is complicated.	Its design is simpler.	
		5	Instructions and data can be fetched simultaneously which increases the operation speed.	Instructions and data have to be fetched in sequential order which limits the operation speed.	

## WINTER- 18 EXAMINATION

Model Answer Subject Code:

17658

Any four Ans: data **Data Type** Size in Bits Data Range/Usage types-4M, **Unsigned char** 0 to 255 8-bit (Each-1M) Signed char 8-bit -128 to + 127 16-bit 0-65535 **Unsigned int** signed int 16-bit -32768 to + 32767 sbit 1-bit SFR bit-addressable only bit 1-bit **RAM bit-addressable only** sfr 8-bit RAM addresses 80 -FFH only What are the features of IEEE 802.11 wireless LAN protocol? 4M c) **IEEE 802.11** Ans: Any 4 Wi-Fi follows the IEEE 802.11 standard. features Supports asynchronous communication. - 4M Provides 1 or 2 Mbps transmission in the 2.4 GHz band. Transmission rates of 1 and 2 Mbps. Provides time bound delivery service. Provides Multicast as well as broadcast services. Continuity of service within extended areas via a distribution system, such as Ethernet. Supports Network management services. Provides registration and authentication service d) Write a program in 'C' language for generating triangular waveform using DAC 0808. 4M NOTE: Program may change. Student can also use the other logic. Please check the logic Correct Ans: and understanding of students. any amount of delay program can also be used. program Program: -4M #include<reg51.h> void main(void)

## WINTER- 18 EXAMINATION <u>Model Answer</u> Subject Code:

17658


f)	Give classification of embedded systems. Explain any one.	4M
	<ol> <li>Reliability: The RTOS is reliable, because it is available for all time and normally it does not fail to perform any function/operation. The reliability of system also depends on the hardware board support package and application code.</li> <li>Predictability: In RTOS, the user knows within How much time period the RTOS is going to perform the task i.e. The RTOS has predictability. We can predict, determine how much time takes by RTOS.</li> <li>Performance: The performance of RTOS is very fast so that it can fulfill all timing requirement.</li> <li>Compactness: The RTOS provide compactness. It required less memory space for storage and hence can be used for portable application, like cellphone, ECG machine, etc.</li> <li>Scalability: RTOS can be used in a wide variety of embedded. They must be able to scale-up or scale-down to suit the application.</li> </ol>	specific tions- 4M, (Each specific tion-1M
Ans:	Key Specifications of RTOS:	Any fo
e)	State any four key specifications of RTOS.	4M
	}	
	\ \\ \}	
	1 1 - u,  }	
	$\begin{cases} P1 = d; \end{cases}$	
	for(d=255; d>=0; d)	
	}	
	P1 = d;	
	{	
	for(d=0; d<=255; d++)	
	{	
	while(1)	
	unsigned char d;	

## WINTER- 18 EXAMINATION <u>Model Answer</u> Subject Code:

17658

11

Ans:



Classific ation-2M and Any one

type detail explanat ion-2M

## Explanation: (any two of the following) 2M

### 1. Stand Alone Embedded Systems

Stand-alone embedded systems do not require a host system like a computer, it works by itself. It takes the input from the input ports either analog or digital and processes, calculates and converts the data and gives the resulting data through the connected device-Which either controls, drives or displays the connected devices. Examples for the stand alone embedded systems are mp3 players, digital cameras, video game consoles, microwave ovens and temperature measurement systems.

### 2. Real Time Embedded Systems

A real time embedded system is defined as, a system which gives a required o/p in a particular time. These types of embedded systems follow the time deadlines for completion of a task. Real time embedded systems are classified into two types such as soft and hard real time systems.

### 3. Networked Embedded Systems

These types of embedded systems are related to a network to access the resources. The connected network can be LAN, WAN or the internet. The connection can be any wired or wireless. This type of embedded system is the fastest growing area in embedded system applications. The embedded web server is a type of system where all embedded devices are connected to a web server and accessed and controlled by a web browser. Example for the LAN networked embedded system is a home security system where all sensors are connected and run on the protocol TCP/IP.

### 4. Mobile Embedded Systems

Mobile embedded systems are used in portable embedded devices like cell phones, mobiles, digital cameras, mp3 players and personal digital assistants, etc. The basic limitation of these devices is the other resources and limitation of memory.

### 5. Small Scale Embedded Systems

These types of embedded systems are designed with a single 8 or 16-bit microcontroller that may even be activated by a battery. For developing embedded software for small scale embedded systems, the main programming tools are an editor, assembler, cross assembler

## WINTER- 18 EXAMINATION

**Model Answer** 

**Subject Code:** 

17658

12

and integrated development environment (IDE).

### 6. Medium Scale Embedded Systems

These types of embedded systems design with a single or 16 or 32 bit microcontroller, RISCs or DSPs. These types of embedded systems have both hardware and software complexities. For developing embedded software for medium scale embedded systems, the main programming tools are C, C++, and JAVA, Visual C++, and RTOS, debugger, source code engineering tool, simulator and IDE.

## 7. Sophisticated Embedded Systems

These types of embedded systems have enormous hardware and software complexities, that may need ASIPs, IPs, PLAs, scalable or configurable processors. They are used for cutting edge applications that need hardware and software Co-design and components which have to assemble in the final system.

Q.	Sub	Answers	Marking
No.	Q. N.		Scheme
3		Attempt any FOUR of the following:	16- Total Marks
	a)	Write 89C 51 program in 'C' language to toggle bits of port P1 continuously.	4M
	Ans:	NOTE: Program may change. Student can also use the other logic. Please check the logic and understanding of students. any other amount of delay program can also be used.  Program: #include < reg 51.h> void delay (unsigned int); void main (void) { while(1) //repeat loop { P1=0xff; //toggle all bits of port1 delay (400); //add delay P1=0x00; //toggle all bits of port1 delay (400); //add delay } } void delay (unsigned int) { Unsigned int x, y;	(Correct program 4M)



## WINTER- 18 EXAMINATION

**Model Answer Subject Code:**  17658

13 for(x=0; x<i; x++) for(y = 0; y < 1275; y++); 4M b) Compare CAN and I2C protocols with respect to: (i) Data transfer rate (ii) **Number of fields** (iii) Addressing bit and (iv) **Application Parameters** (1M Ans: Sr No **CAN** I2C each 1. Data transfer Asynchronous with 250 Synchronous with 3speeds point) 100Kbps, 400 Kbps and 3.4Mbps rate Kbps up-to 1Mbps 2. Number of 08 [including 7 bits of frame 07 fields end and 3 bits of inter frame gap]. Addressing bit 11 bit 7-bit 0r 10 bit address 3. 4. **Applications** Copiers, Telescopes, To interface devices like watch Medical instruments, dog, Flash and RAM memory, Real Elevator controllers. time clock, Microcontrollers Automobile industry c) What is interrupt and event handling in RTOS? Explain in brief. 4M An interrupt is a hardware mechanism used to inform the CPU that an asynchronous event has 4M for Ans: correct A fundamental challenge in RTOS design is supporting interrupts and thereby allowing asynchronous explanat access to internal RTOS data structures. The interrupt and event handling mechanism of an RTOS ion provides the following functions: Defining interrupt handler Creation and deletion of ISR Referencing the state of an ISR Enabling and disabling of an interrupt Changing and referencing of an interrupt mask and help to ensure: Data integrity by restricting interrupts from occurring when modifying a data structure Minimum interrupt latencies due to disabling of interrupts when RTOS is performing critical operations o Fastest possible interrupt responses that marked the preemptive performance of an **RTOS** Shortest possible interrupt completion time with minimum overhead

## **WINTER- 18 EXAMINATION**

**Model Answer Subject Code:**  17658

d)	Give advantages and disadvantages of embedded systems.	4M
Ans:	Advantages of an embedded systems (any two):-	(2 M
	1. <b>Design and Efficiency</b> : The central processing core in embedded system is generally less complicated, making it easier to design. The limited function required of embedded system allows them to design to most efficiently perform their function.	:advan ges , 2M:
	2. <b>Cost:</b> The streamline make-up of most embedded system allows their parts to be smaller less expensive to produce.	disadv ntages
	3. <b>Accessibility:</b> If something goes wrong with certain embedded systems they can be too inaccessible to repair. This problem is addressed in the design stage, so by programming an embedded system. So that it will not affect related system negatively when malfunctioning.	
	4. <b>Maintenance:</b> Embedded systems are easier to maintain because the supplied power is embedded in the system and does not required remote maintenance.	
	Disadvantages (any two):-	
	1. Difficult to change configurations and features: - Once an embedded system is deployed (or finalized), it will be difficult to change its configuration - both its hardware and software. Remote update of software is possible provided the capability is included. Hence, proper requirement analysis is a must before deployment. Hardware configuration change will be much more trickier which may require existing boards be completely replaced. I have seen this happen and it is not pretty.	
	2. <b>Issue of scalability:-</b> Because it is difficult to change configuration, an embedded system cannot be easily scaled up as demand/scope changes. Said so, embedded systems can be designed to scale up for example using expansion ports or networking etc. This means it must be decided before hand during design phase for scale up provisions.	
	3. <b>Limitation of hardware:</b> - With a limited memory or computing capability in most embedded systems, there is always a limitation (or an upper limit) on our software design(upgrade). Be always aware of "Memory" and "Speed".	
	<b>4. Applied for a specific purpose:</b> - By definition, embedded systems are constrained in their objectives. If it is decided to "rehash" an existing embedded system for a completely different purpose, it will normally result in significant change(s) in either or both its hardware or/and software	
e)	Write 89C51 'C' program to rotate stepper motor by 90° in clockwise direction. Motor has step angle of 1.8°.	4M

### WINTER-18 EXAMINATION

Subject Name: Embedded Systems <u>Model Answer</u>

**Subject Code:** 

17658

```
NOTE: Program may change. Student can also use the other logic. Please check the logic
                                                                                                       (correct
Ans:
       and understanding of students.
                                                                                                       logic 4
       Step angle=1.8 degree
                                                                                                       marks)
       For Four step sequence, 1.8 \times 4 = 7.2 \text{ degrees}
       Count for four step sequence = 90/7.2=12.5
       Take count as 12, as 12 X 7.2 = 86.4 degrees, give two more steps for further 3.6 degrees
       #include <reg 51.h>
       void delay();
       void main(void)
       {
       int x;
       for (x=0; x<12; x++)
       P0=0x99;
       delay(10);
       P0=0xcc;
       delay(10);
        P0=0x66;
       delay(10);
       P0=0x33;
       delay(10);
       P0=0x99;
       delay(10);
       P0=0xcc;
       delay(10);
       void delay(unsigned int i)
       unsigned int x,y;
       for(x=0;x<=i;x++)
       for(y=0;y<=1275;y++);
```

	Q. No.	Sub Q. N.	Answers	Marking Scheme
l	4	a)	Attempt any THREE of the following:	12- Total Marks



## **WINTER-18 EXAMINATION**

**Model Answer Subject Code:**  17658

M1 M2 EN	SCON.7 : Serial p SCON.6 : Serial p SCON.5 : Used for	ort mod	•		3 TB8	RB8	TI	0 RI		(2M : format 2M:Bit explan ion)
M1 M2 EN	SCON.7 : Serial p	oort mod	le specif	ier	TB8	RB8	TI	RI		2M:Bit explan
M1 M2 EN	SCON.6 : Serial p	ort mod	•							explan
M1 M2 EN	SCON.6 : Serial p	ort mod	•							ion)
M1 M2 EN	SCON.6 : Serial p	ort mod	•							
M2 EN			ie specit							
EN :	SCON.5. Used IC	ar multin	•		ınicətior	(Makai+	<b>.</b> .			
	SCON.4 : Set/clea	-				•	•			
י אח	SCON.4 : Set/Cier	•			-	•	.1011.			
	SCON.2 : 9th rece					<b>3.</b>				
T S	CON.1 : Transm	it interr	upt flag	. Set by	hardwai	e at the	beginnii	ng of the	stop Bit in	
			-	=			J	Ü		
1 5	SCON.0 : Receive	e interru	pt flag.	Set by h	ardware	halfway	through	the stop	bit time in	
	mode 1.	Must be	e cleared	by soft	ware					
omp	pare serial and pa	arallel co	ommuni	cation(a	ny four	points)				4M
										(1M:
Sr.	Parallel commu	nication			Seria	commur	nication			each
10.										point
	•		lly 8 bits	are	One k	oit at a tin	ne is trai	nsferred s	erially	
2	It requires n- nu	mber of	transmi	ssion	It req	uires one	or two l	ines for da	ata	
	lines for n- bit da	ata			trans	fer				
3	Speed of data tr	ansfer is	fast		Speed	d of data	transfer	is slow		
		ort dista	nce		Prefe	rred for lo	ong dist	ance com	munication	
		is high			Instal	lation cos	st is less			
							76 10 1600			
1 2 3 4	omp	SCON.1: Transm mode1. SCON.0: Receive mode 1. Dispression of the serial and position of the serial of th	SCON.1: Transmit interr mode1. Must be SCON.0: Receive interru mode 1. Must be prompare serial and parallel compare serial and parallel compar	SCON.1: Transmit interrupt flag mode1. Must be cleared SCON.0: Receive interrupt flag. mode 1. Must be cleared ompare serial and parallel communication  T. Parallel communication  Group of data bits, usually 8 bits transferred at a time  It requires n- number of transmi lines for n- bit data  Speed of data transfer is fast  Preferred for short distance communication  Installation cost is high	SCON.1: Transmit interrupt flag. Set by mode1. Must be cleared by softw SCON.0: Receive interrupt flag. Set by h mode 1. Must be cleared by softwompare serial and parallel communication (a parallel co	SCON.1 : Transmit interrupt flag. Set by hardware mode1. Must be cleared by software.  SCON.0 : Receive interrupt flag. Set by hardware mode 1. Must be cleared by software properties of the serial and parallel communication (any four properties).  T. Parallel communication  Group of data bits, usually 8 bits are transferred at a time  It requires n- number of transmission lines for n- bit data transfer is fast Speed of data transfer is fast Speed of data transfer is fast Speed communication  Installation cost is high Instal	SCON.1 : Transmit interrupt flag. Set by hardware at the mode1. Must be cleared by software.  SCON.0 : Receive interrupt flag. Set by hardware halfway mode 1. Must be cleared by software mode 1. Must be cleared	SCON.1 : Transmit interrupt flag. Set by hardware at the beginning mode1. Must be cleared by software.  SCON.0 : Receive interrupt flag. Set by hardware halfway through mode 1. Must be cleared by software  I make the material and parallel communication (any four points)  Tr. Parallel communication  Group of data bits, usually 8 bits are transferred at a time  It requires n- number of transmission lines for n- bit data  Speed of data transfer is fast  Preferred for short distance communication  Installation cost is high  Installation cost is less	SCON.1 : Transmit interrupt flag. Set by hardware at the beginning of the mode1. Must be cleared by software.  SCON.0 : Receive interrupt flag. Set by hardware halfway through the stop mode 1. Must be cleared by software  I Must be cleared by software  I Group of data bits, usually 8 bits are transferred at a time  I It requires n- number of transmission lines for n- bit data  Speed of data transfer is fast  Preferred for short distance communication  Installation cost is high  Set by hardware at the beginning of the mode1. Must be cleared by software  Serial communication  One bit at a time is transferred serial transfer at transfer serial at transfer and transfer serial at transfer serial and parallel communication  It requires one or two lines for data transfer is slow  Preferred for long distance communication  Installation cost is less	SCON.1: Transmit interrupt flag. Set by hardware at the beginning of the stop Bit in mode1. Must be cleared by software.  SCON.0: Receive interrupt flag. Set by hardware halfway through the stop bit time in mode 1. Must be cleared by software  In mode 1. Must be cleared by software halfway through the stop bit time in mode 1. Must be cleared by software  In mode 1. Must be cleared by software  In mode 1. Must be cleared by software.  Serial communication  It requires one or two lines for data transfer in slow  It requires one or two lines for data transfer is slow  In preferred for short distance communication  In preferred for long distance communication communication  Installation cost is high  Installation cost is less

## **WINTER- 18 EXAMINATION**

**Model Answer Subject Code:**  17658

	,	video signals	each )
		Memory: Designer has to make an estimate for memory requirement and must make	<b>,</b>
	۱ ۱	provision for expansion. There are different types of memories in a system ,like	
		RAM, ROM, EEPROM etc. Flash memories are used in embedded system, hence	
		operating systems can be ported in target hardware system.	
	3. I	Reliability: It is the ability that a system will not fail. The ability of system to work	
		properly in all situations without human intervention is called reliability.	
	4.	Safety: It is the probability that system will not cause harm.	
	5. I	NRE cost (Non-Recurring Engineering cost): It is the one-time monetary cost of	
		designing the system. Once system is designed any number of units can be	
	ı	manufactured without incurring any additional design cost.	
	6.	Unit cost: The monetary cost of manufacturing each copy of the system, excluding	
		NRE cost	
		Size: It is measured in terms of the physical space required by the system , memory	
		required in bytes for software and number of gates, transistors in hardware	
		<b>Performance:</b> instruction execution time in the system measures performance.	
		Smaller execution time means higher performance	
		<b>Power:</b> The amount of power consumed by the system which may determine	
		ifetime of battery, or cooling requirement s of the IC, since more power means	
		more heat	
		Flexibility: The ability to change the functionality of the system without incurring heavy NRE cost. Most of the system flexibility is provided by system software	
		<b>Time-to-prototype:</b> The time needed to build a working version of the system, which	
		may be bigger or more expensive than final system implementation, but can be used	
		to verify system's usefulness and correctness and to refine systems functionality	
		<b>Time-to-market:</b> The time required to develop a system to the point that it can be	
		released and sold to customers. The revenue generated in embedded system	
		depends upon this time.	
		Maintainability: The ability to modify the system after its initial release, especially by	
		designers who did not originally design the system	
	14.	Correctness: The implemented system should work functionally correct. To achieve	
	1	this functionality of the system is checked throughout the designing process.	
	15.	Operating system: In desktop the selection of O.S. is limited. In embedded system, a	
		variety of operating systems are Available which can be ported into embedded	
		system. Operating systems like Embedded OS, real Time OS (RTOS) ,and mobile OS ,	
		occupy less area in memory than desktop OS. For real time applications RTOS should	
		be used. Also many open source operating systems are available.	
/iv\	Compar	e RTOS with desktop operating system(any four points)	4M
(iv)	Compar	e KTO3 with desktop operating systemially four points)	4171



# WINTER- 18 EXAMINATION <u>Model Answer</u> Subject Code:

17658

				<del>_</del>   '
	Sr.no	Desktop O.S.	RTOS	each
	1.	Does not have deterministic time response	It has deterministic time response	_ point
	2.	Generalized kernel	Real time kernel	
	3.	There is no task deadline	There is task deadline in RTOS	
	4.	Memory required depends on version	Memory required( footprint) is less	
	5.	Applications are compiled separately from O.S.	Applications are compiled and linked together with RTOS	
	6.	It is used in general desktop computer	It is used in embedded systems	
	7.	It is less reliable	It is more reliable	
	8.	e.g. Windows, Linux	e.g. RTLinux, VXWorks, Micro C / OSII	
(i)		C' program to generate frequency of te the delay.(f <sub>osc</sub> = 12 mHz)	2.5 KHz on P2.7 . Use timer 1 in mode 2 to	6M
(i)	generat	e the delay.(f <sub>osc</sub> = 12 mHz) osc should be in MHz, it seems to be	typing mistake in question as mHz. So if	Calcu
(i)	generat	se the delay.(f <sub>osc</sub> = 12 mHz)  osc should be in MHz, it seems to be as have done the calculation with mH		Calcu ons 2Mar
(i)	Renerate Note: for student Calculate	se the delay.(f <sub>osc</sub> = 12 mHz)  osc should be in MHz, it seems to be as have done the calculation with mH	typing mistake in question as mHz. So if	Calcu ons 2Mar
(i)	Renerate Note: for student Calculate	te the delay.(f <sub>osc</sub> = 12 mHz)  osc should be in MHz, it seems to be as have done the calculation with mH	typing mistake in question as mHz. So if	Calcu ons 2Mar Progr 4
(i)	Renerate Note: for student Calculate	te the delay.(f <sub>osc</sub> = 12 mHz)  osc should be in MHz, it seems to be as have done the calculation with mH  tions: value = 12 MHz.	typing mistake in question as mHz. So if Iz, marks must be given for correct logic.	Calcu ons 2Mar Progr 4
(i)	Renerate Note: for student Calculate	te the delay.(f <sub>osc</sub> = 12 mHz)  osc should be in MHz, it seems to be is have done the calculation with mHz  tions: value = 12 MHz.  Frequency = 2.5khz  Therefore Time period T  Therefore Required time delays	typing mistake in question as mHz. So if iz, marks must be given for correct logic.  T = 1 /2.5KHZ = 0.4 ms ay = 0.4ms / 2 = 0.2 ms = 200usec.	Calcu ons 2Mar Progr 4
(i)	Renerate Note: for student Calculate	te the delay.(f <sub>osc</sub> = 12 mHz)  osc should be in MHz, it seems to be is have done the calculation with mH  tions: value = 12 MHz.  Frequency = 2.5khz  Therefore Time period T  Therefore Required time delay = (12 / F)	typing mistake in question as mHz. So if lz, marks must be given for correct logic.  T = 1 /2.5KHZ = 0.4 ms lay = 0.4ms / 2 = 0.2 ms = 200usec. losc) x number of increments (N)	Calcu ons 2Mar Progr 4
(i)	Renerate Note: for student Calculate	te the delay.(f <sub>osc</sub> = 12 mHz)  osc should be in MHz, it seems to be is have done the calculation with mHz  tions: value = 12 MHz.  Frequency = 2.5khz  Therefore Time period T  Therefore Required time delay = (12 / F  200us = (12 / 12N)	typing mistake in question as mHz. So if iz, marks must be given for correct logic.  T = 1/2.5KHZ = 0.4 ms lay = 0.4ms / 2 = 0.2 ms = 200usec.  Fosc ) x number of increments (N)  HHZ ) x number of increments (N)	Calcu ons 2Mar Progr 4
(i)	Renerate Note: for student Calculate	te the delay.(f <sub>osc</sub> = 12 mHz)  osc should be in MHz, it seems to be is have done the calculation with mHz  tions: value = 12 MHz.  Frequency = 2.5khz  Therefore Time period T  Therefore Required time delay = (12 / F  200us = (12 / 12N)  200us = 1 usec. x	typing mistake in question as mHz. So if iz, marks must be given for correct logic.  T = 1/2.5KHZ = 0.4 ms lay = 0.4ms / 2 = 0.2 ms = 200usec.  Fosc ) x number of increments (N)  HHZ ) x number of increments (N)	Calcu ons 2Mar Progr 4
(i)	Renerate Note: for student Calculate	tions:  Frequency = 2.5khz Therefore Time period T Therefore Required time delay = (12 / F 200us = (12 / 12N) 200us = 1 usec. x N = 200	typing mistake in question as mHz. So if iz, marks must be given for correct logic.  T = 1 /2.5KHZ = 0.4 ms Tay = 0.4ms / 2 = 0.2 ms = 200usec. Tosc) x number of increments (N) The increments (N) N	Calcu ons 2Mar Progr 4
(i)	Renerate Note: for student Calculate	tions:  Value = 12 MHz.  Frequency = 2.5khz  Therefore Time period T  Therefore Required time delay = (12 / F  200us = (12 / 12N)  200us = 1 usec. x  N = 200  Using TIMER 1 in MODE	typing mistake in question as mHz. So if iz, marks must be given for correct logic.  T = 1 / 2.5KHZ = 0.4 ms lay = 0.4ms / 2 = 0.2 ms = 200usec. losc) x number of increments (N) IHZ) x number of increments (N) N	Calcu ons 2Mar Progr 4
(i)	Renerate Note: for student Calculate	se the delay.(f <sub>osc</sub> = 12 mHz)  osc should be in MHz, it seems to be is have done the calculation with mHz  tions: value = 12 MHz.  Frequency = 2.5khz  Therefore Time period T  Therefore Required time delay = (12 / F  200us = (12 / 12M)  200us = 1 usec. x  N = 200  Using TIMER 1 in MODE COUNT	typing mistake in question as mHz. So if Iz, marks must be given for correct logic.  T = 1/2.5KHZ = 0.4 ms Tay = 0.4ms / 2 = 0.2 ms = 200usec. Tosc) x number of increments (N) THZ) x number of increments (N) N  E 2, The second control of the	Calcu ons 2Mar Progr
(i)	Renerate Note: for student Calculate	tions:  Value = 12 MHz.  Frequency = 2.5khz  Therefore Time period T  Therefore Required time delay = (12 / F  200us = (12 / 12N)  200us = 1 usec. x  N = 200  Using TIMER 1 in MODE  COUNT = 2	typing mistake in question as mHz. So if iz, marks must be given for correct logic.  T = 1 / 2.5KHZ = 0.4 ms lay = 0.4ms / 2 = 0.2 ms = 200usec. losc) x number of increments (N) IHZ) x number of increments (N) N	Calcu ons 2Mar Progr
(i)	Renerate Note: for student Calculate	se the delay.(f <sub>osc</sub> = 12 mHz)  osc should be in MHz, it seems to be is have done the calculation with mHz  tions: value = 12 MHz.  Frequency = 2.5khz  Therefore Time period T  Therefore Required time delay = (12 / F  200us = (12 / 12M)  200us = 1 usec. x  N = 200  Using TIMER 1 in MODE COUNT	typing mistake in question as mHz. So if Iz, marks must be given for correct logic.  T = 1/2.5KHZ = 0.4 ms Tay = 0.4ms / 2 = 0.2 ms = 200usec. Tosc) x number of increments (N) THZ) x number of increments (N) N  E 2, The second control of the	Calcu ons 2Mar Progr
(i)	Reneration Note: for student Calculate Crystal	tions:  Value = 12 MHz.  Frequency = 2.5khz  Therefore Time period T  Therefore Required time delay = (12 / F  200us = (12 / 12N)  200us = 1 usec. x  N = 200  Using TIMER 1 in MODE  COUNT = 2	typing mistake in question as mHz. So if Iz, marks must be given for correct logic.  T = 1/2.5KHZ = 0.4 ms Tay = 0.4ms / 2 = 0.2 ms = 200usec. Tosc) x number of increments (N) THZ) x number of increments (N) N  E 2, The second control of the	Calcu ons 2Mar Progr 4



### **WINTER-18 EXAMINATION**

Model Answer Subject Code:

17658

```
void main(void)
              TMOD=0x20;//timer1 mode2
              TH1=0X38; // Load count
              TR1=1; // start timer1
              while (1)
                          // repeat forever
              while (TF1= = 0); // wait for Timer to overflow
              SQR = ~SQR; // toggle bit P2^7
              TF1=0; // clear TF1
              }// end of while
              }// end of main
(ii)
       Draw the labeled diagram of LCD interface with 89C 51. Write a program in 'C' language to
                                                                                                     6M
       display "WELCOME" on LCD.
Ans:
       Note: Student may use any other method
                                                                                                     interfaci
                                                                                                     ng
                               P1.0
                                               DO
                                                                                                     diagram
                                             8
                               P1.1
                                               D1
                                             9
                                                                                                     : 02M,
                               P1.2
                                               D2
                                                       2 Line X 16 Character
                               P1.3
                                               D3
                                                                                                     program
                                                           LCD Display
                               P1.4
                                               D4
                                                                                                     : 04M)
                               P1.5
                                               D<sub>5</sub>
                           C
                                            13
                               P1.6
                                               D<sub>6</sub>
                                               D7 E
                               P1.7
                                                      R/W RS GND Vo VCC
                               P3.3
                               P3.2
                               P3.4
       PROGRAM:
       #include <reg 51.h>
       Sbit rs=P3^4;
       Sbit rw=P3^2;
       sbit en=P3^3;
       void delay(unsigned int);
       void lcdcmd(unsigned char);
       void lcddta(unsigned char);
       void main( void )
       rs=0;
       rw=0;
       en=0;
       Icdcmd(0x38);
```

### WINTER-18 EXAMINATION

Subject Name: Embedded Systems <u>Model Answer</u> Subject Code:

17658

20

delay(10); lcdcmd(0x0e); delay(10); lcdcmd(0x06); delay(10); lcdcmd(0x01); delay(10); lcdcmd(0x80); delay(10); lcddta('W'); delay(10); lcddta('E'); delay(10); lcddta('L'); delay(10); lcddta('C'); delay(10); lcddta('O'); delay(10); lcddta('M'); delay(10); lcddta('E'); delay(10); while(1); } } void lcddta(unsigned char dta) { rs=1; rw=0; P1=dta; en=1; delay(2); en=0; void lcdcmd(unsigned char cmd) { rs=0; rw=0; P1=cmd; en=1; delay(2);

## WINTER- 18 EXAMINATION

Subject Name: Embedded Systems <u>Model Answer</u> Subject Code:

17658

21

en=0;
}
void delay(unsigned int t)
{
Unsigned in tx,y;
for(x=0;x<=t;x++)
for(y=0;y<=1275;y++);
}

).	Sub Q. N.		Answers	Marking Scheme
		Attempt any FOUR of the following:		16- Total Marks
	a)	Write 89C51 'C' program to transfer character 'MSBTE' serially at 9600 baud rate continuously, use 8 bit data and 1 stop bit. Assume crystal frequency of 11.0592 MHz.		
	Ans:	NOTE: Program may change. Student can and understanding of students.  #include <reg51.h> void main(void)</reg51.h>	also use the other logic. Please check the logic	4M for correct program
		{ unsigned char text[] = "MSBTE"; TMOD = 0x20; TH1 = 0xFD; SCON = 0x50; bit, REN)	//initialize array //Initialize timer 1 in mode 2 //baud rate 9600 //start serial communication ( 8bit , 1 stop	
		TR1 = 1; for(i=0; i<6; i++) { SBUF = text[i];	//start timer 1 //Read array and transmit serially till end	
		while(TI==0); TI = 0; }	//check interrupt //clear interrupt	
	b)	Describe the need of RS-232 and MAX-232	2 with a suitable diagram.	4M

## WINTER- 18 EXAMINATION Model Answer Subject Code:

17658

22

2M -RS-232

2M -

MAX

(1M for any two

needs &


1M for diagram

each)

232

## Ans: Need of RS232:

- RS-232 is a standard by which two serial devices communicate (recommended standard)
- The RS-232 interface is the Electronic Industries Association (EIA) standard for the interchange of serial binary data between two devices.
- It was initially developed by the EIA to standardize the connection of computers with telephone line modems
- The connection must not be longer than 50 feet. (15 m)
- The standard defined voltage levels made it immune to noise disturbances and reduced the error in data exchange.
- The maximum slew rate in RS232 is limited to 30V/μs. Also, a maximum bit rate of 20 Kbps is also defined. These limitations of the standard help in reducing the cross talk with adjacent signals.




#### Need of MAX 232:

 A line driver such as the MAX232 chip is required to convert RS232 voltage levels to TTL levels, and vice versa.


## WINTER- 18 EXAMINATION <u>Model Answer</u> Subject Code:

ect Code: 17658



# WINTER- 18 EXAMINATION <u>Model Answer</u> Subject Code:

17658





## WINTER- 18 EXAMINATION

Model Answer Subject Code:


17658

25

IS	too	high

Example:

Process	Burst time
P1	53
P2	17
Р3	68
P4	24



- The Gantt chart is:
- Typically, higher average turnaround than SJF, but better response

• Cross compiler

Locators

• Loaders


• Simulators

Debugger

## WINTER- 18 EXAMINATION Model Answer

**Subject Code:** 

17658



WINTER- 18 EXAMINATION **Model Answer Subject Code:** 

17658

27

• Integrated development environment (IDE).

The function of

- 1) Compiler: It is a computer program that transforms the source code written in a programming or source language into another computer language i.e. target language i.e. binary code known as object code.
- 2) Cross assembler: It is useful to convert object codes for microcontrollers or processor to other codes for another microcontrollers or processor and vice versa.
- 3) Cross compiler: It is used to create executable code other than one on which the compiler is run. They are used to generate executable for embedded systems or multiple platforms.
- 4) Linker/Locator: It is used for relocation process. It is done during compilation also it can be done at run time by a relocating loader. It is a program that takes one or more objects generated by compiler and combines them into a single executable program.
- 5) **Simulators:** A simulator is the s/w that simulates an h/w unit like emulator, peripheral, network and I/O devices on a PC. It defines a processor or processing device as well as various versions for the target system. Monitors the detailed information of as source code part with labels and symbols during the execution for each single step. Provides the detailed information of the status of memory RAM and simulated ports, simulated peripheral devices of the defined target system.
- 6) **Debugger:** Allows you to download your code to the emulator's memory and the control all of the functions of the emulator from a PC. Common debugging features include the capability to examine and modify the microcontroller's on chip registers, data- and program-memory; pausing or stopping program executing at defined program locations by setting breakpoints; single-stepping (execute one instruction at a time) through the code and looking at a history of executed code (trace).
- 7) Integrated Development Environment (IDE):- An IDE is a software application that provides comprehensive facilities to computer programmers for software development. An IDE consists of:
  - A source code editor.
  - A compiler and or interpreter.
  - **Build automation tools**
  - A debugger.

IDE is dedicated to a specific programming language, allowing a feature set that most closely matches the programming paradigms [model] of the language. IDE's typically present a single program in which all development is done. This program typically provides many features for authoring, modifying, compiling, deploying, and debugging software.

#### WINTER- 18 EXAMINATION **Subject Code:** Model Answer

17658

28 f) Draw and explain the interfacing of DC motor with 89C51 microcontroller. **4M** Ans: 2M +5V Interfaci +5V ng 2M 40 31 explanat EA Vcc ion 10uF/10V + 6V DC +SV DC RST R1 8.2K IC1 AT89S51 P1.0 6V / 250mA IC2 DC motor L2930 19 XTAL1 11.0592MHz 18 12 13 XTAL2 33pf GND **Explanation:** The maximum current which can be sunk from 89C51 is upto 15mA at 5V. But DC motor needs more current depending on its type. Hence DC motor cannot be connected directly to the microcontroller. L293D motor driver stops the back emf produced by the motor from affecting the microcontroller. Port pins P1.0 and P1.1 are connected to the input pins 2 and 7 of L293D motor driver. The output pins of the L293D ,pin 3 and 6 are connected to the DC motor. Direction of the rotation of the motor can be changed by inverting the output terminals

#### **WINTER-18 EXAMINATION Model Answer Subject Code:**


17658

Q. No.	Sub Q. N.	Answers		Marking Scheme
6.		Attempt any FOUR of the following:		16- Tota Marks
	a)	What is function of JTAG port? Explain in brief.		4M
	Ans:	<ul> <li>The functionality usually offered by JTAG is Debug Access</li> <li>Debug Access is used by debugger tools to access the internals resources and functionality available and modifiable,         <ul> <li>e.g. registers, memories and the system state.</li> </ul> </li> <li>Boundary Scan is used by hardware test tools to test the physic e.g. on a PC.</li> </ul> AVR Dragon JTAG connector	of a chip making its	4 M Explana ion
		TCK 1 TDO 3 TMS 5 TDI 9 VTref 4 GND 2/10 NC 7 nSRST 6	TCK TDO TMS Target AVR CORD RST	

## WINTER- 18 EXAMINATION **Model Answer**

**Subject Code:** 

17658



- The DTAB (Debug and Test Access Block) is implemented on the target chip as a "passive" device that never sends data without request.
- The DTAB mainly consists of the following:
  - The TAP (Test Access Port) with its physical connections (signals) to the external world.
  - The TAP Controller (a 16-state state machine).
  - One IR (Instruction Register)
  - and several DRs (Data Registers).
  - The Debug Bus for communication with the on-chip debug logic.
- The TAP defines the interface between the DTAB and the debug tool.
- The IEEE standard defines the following TAP signals, used for the serial communication and driving the TAP controller
- TDI: Test Data In: serial data from debugger to target
- TDO: Test Data Out: serial data from target to debugger
- TCK: Test Clock
- TMS: Test Mode: Select controls the TAP controller state transitions



# WINTER- 18 EXAMINATION <u>Model Answer</u> Subject Code:

17658

b)	State any four features of Bluetooth technology.	4M
Ans:	Features:	1M
	Short range Radio Frequency at 2.4 GHz	
	Point-to-point or point-to-multiple points	
	Voice and Data	
	Transmit through walls up to 10m	
	Supports both synchronous and asynchronous services	
	Bluetooth 1.x supports data rate up to 1Mbps.	
	Bluetooth 2.0 enhanced maximum data rate of 3Mbps over 100m.	
	Bluetooth devices use a protocol called (FHSS) Frequency-Hopping Spread Spectrum	




## WINTER- 18 EXAMINATION

Model Answer

**Subject Code:** 


17658



## WINTER- 18 EXAMINATION **Subject Name: Embedded Systems**

**Subject Code: Model Answer** 

17658





# WINTER- 18 EXAMINATION <u>Model Answer</u> Subject Code:

17658

